WRT-27

3473

US Model
Canadian Model



UHF TRANSMITTER

SPECIFICATIONS

Transmitter and modulator sections

Carrier frequency	USA model: 947 – 952 MHz Canadian model: 902 – 928 MHz (Refer to the serial number plate)
Modulation	F_3 (Frequency modulation)
RF power output	USA model: 30 mW (into a 50Ω load) Canadian model: 35 mW (into a 50Ω load)
Oscillator	Crystal-controlled
Frequency stability	USA model: within ±0.005% Canadian model: within ±0.01%
Multiplication	48
Pre-emphasis	50μ sec
Deviation	±2.4 kHz (at 1 kHz) from −20 dB to −60 dB continuously adjustable (0 dB = 1 Vrms)
Attenuator adjustable range	Approx. 40 dB
Audio distortion	Less than 0.1% (±2.4 kHz deviation, at 1 kHz)
Signal-to-noise ratio	Better than 50 dB (±2.4 kHz deviation, at 1 kHz)
Antenna	Approx. ¼ wave length flexible wire
LED level indicator	illuminates at more than ±2.4 kHz deviation
LED battery checker	At more than 7 V, illuminates momentarily when the power is turned on
Input impedance	Approx. 4 k ohms (at 1 kHz) balanced input

Power section

Standard operating voltage	9 V
Minimum operating voltage	7 V
Current drain	45 mA or less
Battery life	Approx. 2 hours (with Eveready No. 522)
Battery	Size 6F22, alkaline (Eveready No. 522, NEDA 1604A or equivalent)

General

Finish	Satin-nickel plate
Operating temperature	5°C to 60°C (41°F to 140°F)
Storage temperature	5°C to 60°C (41°F to 140°F)
Dimensions	Approx. 59×93×20 mm (w/h/d) ($2\frac{3}{8}\times3\frac{5}{8}\times\frac{13}{16}$ inches)
Weight	Approx. 170 g (6 oz) Not including a battery

Microphone section (equivalent to ECM-50PS)

Type	Electret Condenser Microphone
Directivity	Omni-directional
Power supply	Supplied from transmitter
Microphone cable	2.2 dia.×1200 mm ($\frac{1}{16}$ dia.×47¼ inches) equipped with 4-pin connector
Dimensions	10.6 dia.×21 mm ($\frac{1}{16}$ dia.×$\frac{13}{16}$ inches)
Weight	Microphone: approx. 85 g (0.3 oz) With connector: approx. 27 g (1 oz)
Finish	Satin-nickel plate

MICROFILM

SONY®

SERVICE MANUAL

3473

SECTION 1
OUTLINE

1-1. BLOCK DIAGRAM



1-2. LEVEL DIAGRAM





SECTION 2
DISASSEMBLY

Note: Follow the disassembly procedure in the numerical order given.

Battery Case



Front Case





Center Panel (1)



Chassis Cover



MOD, OSC Board



Terminal Plate Ass'y



Center Panel (2)



RF Unit



Sub Panel



ATT



RF Case (A), (B)



Supplied Microphone Cord (miniconnector wiring)


❷ K1.4 x 1.6, precision
❹
❶ Install the connector to the unit.
❻ Remove lead wires.
red lead wire
white lead wire
shielded
❸ Hold the cable bushing so that it does not move.
❺ spacer, connector

Microphone Cord (miniconnector wiring)



Microphone Cord (Cannon Type Connector Wiring)



SECTION 3
ADJUSTMENTS

CONNECTION DIAGRAM



ADJUSTMENT PARTS LOCATION



<table>
<tr><th>Adjustment Parts</th><th>Remarks</th><th>Ammeter Reading</th></tr>
<tr><td>CT201, 202</td><td>Adjust for a maximum reading on the ammeter.
(Repeat 2 or 3 times.)</td><td>4 mA or more</td></tr>
<tr><td>CT203, 204</td><td>Adjust for a maximum reading on the ammeter.
(Repeat 2 or 3 times.)</td><td>7 mA or more</td></tr>
<tr><td>CT205</td><td>Adjust for a maximum reading on the ammeter.</td><td>10 mA or more</td></tr>
<tr><td>CT206</td><td>1. Adjust for a maximum reading on the ammeter.
2. Make sure that:
• Reading on the ammeter is more than 17 mA.
• Clearance (A) is 0.3 mm or less.
3. If necessary, adjust L204 as follows and repeat steps 1, 2.
 

<table><tr><td>clearance: more than 0.3 mm</td><td>Widen L204</td></tr><tr><td>clearance: none</td><td>Narrow L204</td></tr></table></td><td>17 mA or more
 
</td></tr>
<tr><td>CT207</td><td>1. Adjust for a maximum reading on the ammeter.
2. Make sure that:
• Reading on the ammeter is more than 30 mA.
• Clearance (A) is 0.3 mm or less.
3. If necessary, adjust L205 as follows and repeat steps 1, 2.
 

<table><tr><td>clearance: more than 0.3 mm</td><td>Bend L205 in the direction shown by the arrow ①.</td></tr><tr><td>clearance: none</td><td>Bend L205 in the direction shown by the arrow ②.</td></tr></table></td><td>30 mA or more</td></tr>
<tr><td>CT208, 209</td><td>The 48 fo frequency becomes maximum.</td><td></td></tr>
</table>

OVERALL ADJUSTMENT

1. Connect the equipment as shown in Fig. A in the next page.
2. Adjust CT209 to obtain maximum frequency level at 48fo and best spurious response. At this time make sure that the spurious and harmonics emission is at least 50 dB or more below carrier.
3. Connect the equipment as shown in Fig. B on the next page.
4. Tune the linear detector accurately.
5. Set the frequency deviation to ±150 kHz by adjusting the attenuator (ATT).
6. Adjust RT101 for the minimum distortion.
7. Turn off the AF oscillator to stop the modulation and adjust L102 so that the reading on the frequency counter is as follows.

Channel	US	CANADA	Channel	US	CANADA
11	947.25	902.75	25	948.50	914.75
12	948.25	904.00	26	–	916.75
13	950.25	905.00	27	–	918.50
14	951.75	908.25	28	–	921.50
15	949.00	909.00	31	949.25	914.25
16	–	911.00	32	948.75	917.25
17	–	912.75	33	950.00	919.00
18	–	915.75	34	951.50	921.00
21	947.75	908.50	35	–	921.75
22	949.75	909.75	36	–	925.00
23	950.75	910.75	37	–	926.00
24	951.25	914.00	38	–	927.25

Unit: MHz
Standard: $^{+0.005}_{-0}$ MHz

8. Repeat steps 4 to 7 a few times until the best distortion characteristic is obtained and the set is adjusted to the specified frequency. The distortion should be less than 1 %.
9. Repeat steps 1 through 8.
10. Ascertain that the spurious response ratio is 50 dB or more when changing the voltage between 7 V and 9 V. If it is less than 50 dB, repeat adjustments.

CONNECTION DIAGRAM





Fig. A



Fig. B

ADJUSTMENT PARTS LOCATION



LENGTH OF ANTENNA CORD





SECTION 4
DIAGRAMS

4-1. MOUNTING DIAGRAM

- Semiconductor Lead Layouts

2SA1027R



2SC634A
2SC1636



2SC668D



2SK42



2SK43



6519-5



1S1555
RD5.6E
FC52-C



ERA81



TLR102



Note:
- [ ]← : indicates side identified with part number.



Q	D
	301
109	
	104
	103
108	
107	
110	
104	
103	102
111	
102	105
101	106
	101
105	
106	

4-2. SCHEMATIC DIAGRAM



Note:

- All capacitors are in μF unless otherwise noted. pF : μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in ohms, 1/8 W unless otherwise noted. kΩ : 1000 Ω, MΩ : 1000 kΩ
- ☐ : panel designation.
- Readings are taken under no-signal conditions with a VOM (20 kΩ/V).
- ( ): voltage when D301 is on.
- ※ : measured by spectrum analizer with capacitor (2 pF)
- 0 dB = 1 mW/50 Ω

SECTION 5
EXPLODED VIEWS

5-1.



Note:
- Items marked "♦" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

5-2.

Note:
- Items marked "♦" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


A-4580-003-A Screen Ass'y, wind
X-2511-809-1 Clip Ass'y
♦ 2-522-026-00 Terminal
♦ 2-522-024-00 Plate, ground
2-511-819-00 Bushing, cable
♦ 2-522-027-00 Case, rear
A-4510-007-A Capsule Ass'y
♦ 2-522-025-00 Screw
⊕ K1.4 x 1.6, precision
1-551-277-00 Cable, supplied microphone
1-560-155-00 Connector with plug
2-527-512-00 Spacer, connector
2-527-017-00 Cover, connector
2-523-606-00 Clamp, cord
2-511-819-00 Bushing, cable
■ C 1-534-685-00 Cord, microphone
■ A 1-560-228-00 Connector, cannon type
■ B 1-560-155-00 Connector, plug
♦ 1-551-710-00 Cable, microphone; including parts marked ■ A–C

SECTION 6
ELECTRICAL PARTS LIST

Ref. No.	Part No.	Description		
		SEMICONDUCTORS		
		Transistors		
Q101	8-723-303-23	2SK43		
Q102	8-729-612-77	2SA1027R		
Q103	8-761-622-00	2SC1636		
Q104	8-729-612-77	2SA1027R		
Q105	8-729-806-84	2SC668D		
Q106	8-727-311-03	2SK42		
Q107	8-726-387-00	2SC634A		
Q108	8-761-622-00	2SC1636		
Q109	8-726-387-00	2SC234A		
Q110	8-727-311-03	2SK42		
Q111	8-726-387-00	2SC634A		
Q301	8-765-195-03	6519-5		
		Diodes		
D101	8-719-900-50	FC52-C		
D102	8-719-156-25	RD5.6E		
D103	8-719-815-55	1S1555		
D104–106	8-719-981-01	ERA81		
D301	8-719-801-02	TLR102		
		CAPACITORS		
All capacitors are in μF and tantalum unless otherwise noted. p: μμF.				
C101	1-131-254-00	1	10 V	
C102	1-131-270-00	4.7	20 V	
C103	1-131-254-00	1	10 V	
C104	1-131-274-00	0.047	35 V	
C105	1-131-256-00	10	10 V	
C106	1-131-264-00	0.47	20 V	
C107	1-131-256-11	10	10 V	
C108	1-161-028-00	0.0022	25 V	ceramic (semiconductor)
C109	1-102-972-00	91 p	50 V	ceramic
C110, 111	1-101-880-00	47 p	50 V	ceramic
C112	1-131-270-00	4.7	20 V	
C113	1-131-262-00	0.22	20 V	
C114	1-131-256-00	10	10 V	
C115	1-131-262-00	0.22	20 V	
C116, 117	1-131-256-00	10	10 V	
C118	1-161-028-00	0.0022	25 V	ceramic (semiconductor)
C228	1-101-837-21	0.5 p	50 V	ceramic
C229, 230	1-161-032-00	0.01	25 V	ceramic (semiconductor)
C231	1-161-026-00	0.001	25 V	ceramic (semiconductor)
		RESISTORS		
All resistors are in ohms and 1/8 W carbon.				
R101, 102	1-246-807-00	100 k		
R103	1-246-860-00	24 k		
R104	1-246-771-00	100		
R105	1-246-848-00	2.4 k		
R106	1-246-785-00	1.5 k		
R107	1-246-790-00	3.9 k		
R108	1-246-802-00	39 k		
R109	1-246-778-00	390		
R110	1-246-805-00	68 k		
R111	1-246-797-00	15 k		
R112	1-246-853-00	6.2 k		
R113	1-246-847-00	2.0 k		
R114	1-246-802-00	39 k		
R115	1-246-846-00	1.6 k		
R116	1-247-047-00	330 k		
R117	1-246-807-00	100 k		
R118	1-246-783-00	1 k		
R119	1-246-862-00	36 k		
R120	1-246-867-00	100 k		
R121	1-246-789-00	3.3 k		
R122	1-246-799-00	22 k		
R123	1-246-849-00	3 k		
R124	1-246-771-00	100		
RV301	1-226-942-00	10 k, variable; ATT		
RT101	1-223-158-00	100 k, adjustable		

Ref. No.	Part No.	Description
		MISCELLANEOUS
L101	1-407-823-00	100 μH, microinductor
L102	1-426-011-00	Coil, OSC
L103	1-405-786-00	Coil, 8.2 μH
T101	1-427-339-11	Transformer
CNJ301	1-561-309-00	Socket, connector
S301	1-552-190-00	Switch, power
	1-526-667-00	Socket, crystal
	•1-603-431-00	Printed Circuit Board, crystal hold
	•A-4518-111-A	Complete Circuit Board, MOD OSC
X301	1-527-744-00 to 1-527-748-00	Crystal OSC (11CH) (US model) to Crystal OSC (15CH) (US model)
	1-527-749-00 to 1-527-753-00	Crystal OSC (21CH) (US model) to Crystal OSC (25CH) (US model)
	1-527-754-00 to 1-527-757-00	Crystal OSC (31CH) (US model) to Crystal OSC (34CH) (US model)
X301	1-527-758-00 to 1-527-765-00	Crystal OSC (11CH) (Canadian model) to Crystal OSC (18CH) (Canadian model)
	1-527-766-00 to 1-527-773-00	Crystal OSC (21CH) (Canadian model) to Crystal OSC (28CH) (Canadian model)
	1-527-774-00 to 1-527-781-00	Crystal OSC (31CH) (Canadian model) to Crystal OSC (38CH) (Canadian model)

ACCESSORIES & PACKING MATERIALS

Part No.	Description
2-527-009-00	Case, leather
2-527-061-00	Carton, individual
2-527-062-00	Carrying Case
•2-527-514-11 to 38	Seal, channel
2-599-123-22	Manual, instruction
2-527-550-00	Bag, polyethylene
3-701-623-00	Bag, polyethylene

• Items marked "•" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

DIMENSIONS AND PART NO. OF PRECISION SCREWS

⊕ *K*
(Flat-countersunk-head screw)

Type	Size (mm) (d × L)	Part No. Black	Part No. Silver
Type 1	K1.4 × 1.6	7-627-451-08	7-627-451-07
	K1.4 × 1.8		
	K1.4 × 2	7-627-451-38	7-627-451-37
	K1.4 × 2.2		
	K1.4 × 2.5	7-627-451-18	7-627-451-17
	K1.4 × 2.8		
	K1.4 × 3	7-627-451-28	7-627-451-27
	K1.4 × 3.5		7-627-451-47
	K1.4 × 4		
	K1.4 × 4.5		
	K1.4 × 5	7-627-451-78	7-627-451-77
	K1.7 × 1.8		
	K1.7 × 2		
	K1.7 × 2.2		
	K1.7 × 2.5		
	K1.7 × 2.8		
	K1.7 × 3		
	K1.7 × 3.5		
	K1.7 × 4	7-627-450-78	
	K1.7 × 4.5		
	K1.7 × 5		
	K1.7 × 5.5		
	K1.7 × 6		
	K2 × 2	7-627-452-08	7-627-452-07
	K2 × 2.2		
	K2 × 2.5		
	K2 × 2.8		
	K2 × 3	7-627-452-18	7-627-452-17
	K2 × 3.5		
	K2 × 4	7-627-452-28	
	K2 × 4.5		
	K2 × 5	7-627-452-38	
	K2 × 5.5		
	K2 × 6		
	K2 × 7		
	K2 × 8		

⊕ *P*
(Pan-head screw)



Type	Size (mm) (d × L)	Part No. Black	Part No. Silver
Type 1	P1.4 × 1.4		7-627-551-47
	P1.4 × 1.6	7-627-551-08	7-627-551-07
	P1.4 × 1.8		
	P1.4 × 2	7-627-551-18	7-627-551-17
	P1.4 × 2.2		
	P1.4 × 2.5	7-627-551-28	7-627-551-27
	P1.4 × 2.8	7-627-551-88	
	P1.4 × 3	7-627-551-58	7-627-551-57
	P1.4 × 3.5	7-627-551-68	7-627-551-67
	P1.4 × 4	7-627-551-78	7-627-551-77
	P1.4 × 4.5		
	P1.4 × 5	7-627-551-38	7-627-551-37
	P1.7 × 1.6	7-627-552-18	
	P1.7 × 1.8		
	P1.7 × 2	7-627-552-28	7-627-552-27
	P1.7 × 2.2		
	P1.7 × 2.5	7-627-552-08	7-627-552-07
	P1.7 × 2.8		
	P1.7 × 3	7-627-552-38	7-627-552-37
	P1.7 × 3.5	7-627-552-78	
	P1.7 × 4	7-627-552-48	7-627-552-47
	P1.7 × 4.5		7-627-552-67
	P1.7 × 5	7-627-552-58	7-627-552-57
	P1.7 × 5.5		
	P1.7 × 6		
	P2 × 1.8		
	P2 × 2	7-627-553-18	7-627-553-17
	P2 × 2.2		7-627-554-07
	P2 × 2.5	7-627-553-28	7-627-553-27
	P2 × 2.8		
	P2 × 3	7-627-553-38	7-627-553-37
	P2 × 3.5		7-627-554-17
	P2 × 4	7-627-553-48	7-627-553-47
	P2 × 4.5	7-627-553-58	7-627-553-57
	P2 × 5		7-627-553-67
	P2 × 5.5		
	P2 × 6		
	P2 × 7	7-627-553-88	7-627-553-87
	P2 × 8	7-627-553-98	7-627-553-97
	P2 × 10	7-627-553-78	7-627-553-77
Type 3	P1.4 × 1.4		7-627-850-37
	P1.4 × 1.6		7-627-850-47
	P1.4 × 1.8		7-627-850-77
	P1.4 × 2	7-627-850-08	7-627-850-07
	P1.4 × 2.2		
	P1.4 × 2.5	7-627-850-18	7-627-850-17
	P1.4 × 2.8		
	P1.4 × 3	7-627-850-28	7-627-850-27
	P1.4 × 3.5	7-627-850-58	7-627-850-57
	P1.4 × 4	7-627-850-68	7-627-850-67
	P1.4 × 4.5		7-627-851-17
	P1.4 × 5		7-627-851-27

9-954-968-11

Sony Corporation
© 1981

81C0546-1
Printed in Japan